

GUTTERS

Zincalume® Flashings List

Type 1 	Type 2 	Type 3 	Type 4 	Type 5
Type 6 	Type 7 	Type 8 	Type 9 	Type 10
Type 11 	Type 12 	Type 13 	Type 14 	Type 15
Type 16 	Type 17 	Type 18 	Type 19 	Type 20

CAPPINGS

Type 21 	Type 22 	Type 23 	Type 24 	Type 25
Type 26 	Type 27 	Type 28 	Type 29 	Type 30
Type 31 	Type 32 	Type 33 	Type 34 	Type 35

FLASHINGS

Type 36 	Type 37A 	Type 38 	Type 39 	Type 40
Type 41 	Type 42 	Type 43 	Type 44 	Type 45
Type 46 	Type 47 	Type 48 	Type 49 	Type 50